



DRYER ASSEMBLIES

Functions of an AC Dryer:

1. To act as a temporary storage container for oil and refrigerant when neither are needed for system operation.
2. Trap debris that may be inside the A/C system.
3. Absorb moisture (water) that may have gotten inside the A/C system.

Application	Part No.	Description
416F2, 420F2, 426F2, 427F2, 428F2, 430F2, 432F2, 434F2, 444F2	4155056	DRYER AS - (RECEIVER)
225, 235, 245, 621B, 623B, 627B, 637D, 663D, D7G, D8K	6P1309	DRYER - (RECEIVER)
550B, 560B, 574B, 580B, D350E, D400E	1065532	DRYER - (RECEIVER)
12G, 14G, 16G, 120G, 130G, 140G, 988F, 994/D/F	1065533	DRYER - (RECEIVER)
416B, 426B, 428B, 631E, 633E, 637E, 814B, 816B, 824C	1065534	DRYER - (RECEIVER)
120H, 135H, 140H, 160H, 814F, 824H, 943H, 950G, 962G	1757162	DRYER - (RECEIVER)
315D, 318D, 320C, 324D, 325D, 329D, 330D	1761902	DRYER - (RECEIVER)
311B, 315B, 318B, 320B, 322B, 330B, 345B, 365B	1133497	RECEIVER AS
120K, 140K, 160K, 325D, 330D, 814F, 815F, 816F, C18, C27, C32	2573227	DRYER AS
621H, 623H, 627H, 735B, 740B, 844K, 854K, 966K, 972K, 992K	3200563	DRYER AS
785G, 815K, 816K, 824K, 825K, 966M, 972M, 980M, 988K, 990K	3551793	DRYER AS

*Other part no. not included in the list are available. Please contact your sales representative if you have any questions.
Part Numbers are used for reference purposes only