



ARMATURES

Armatures are electro-magnets located inside an electrical motor. Armatures are composed of thin metal plates stacked together forming poles, with thin copper wire coiled around each pole.

Part No.	Description	Application
0949885	ARMATURE SET	311, 312, 320, 320 L, 320N, E110, E110B, E120, E120B, E140, E200B, E70, E70B
1239776	ARMATURE AS-STARTING MOTOR	5130B, 836, 966F II, 980G, D10R, D11R, D7R II, D8R, D8R II, D9R
1275950	ARMATURE AS	307, 311B, 311C, 311D LRR, 312C, 312C L, 312D, 312D L, 313D, 314C, 314D CR, 314D LCR, 315, 315B, 315C, 315D L, 317B LN, 318B, 318C, 318D L, 319C, 319D, 319D L, 319D LN, 320B, 320C, 320C FM, 320C L
2Y2384	ARMATURE AS	120B, 140B, 3306, 3408B, 631E, 930, 930R, D4E SR, D5E, D6C, D6D, D6E SR, D8L, G3306
3E7855	ARMATURE AS-STARTER	120H, 120H ES, 120H NA, 120K, 120K 2, 12K, 135H, 135H NA, 140G, 140K, 140K 2, 160K, 214B, 3116, 3126, 3126B, 3126E, 320B, 322B L, 322B LN, 322C, 322C FM, 324D, 324D FM, 324D FM LL, 324D L, 324D LN
3T0867	ARMATURE AS	120G, 12G, 130G, 140G, 14G, 160G, 1673C, 16G, 215, 215B, 235, 245, 3176B, 3176C, 3196, 3208, 330 L, 3304, 3304B, 3306, 3306B, 3306C, 3406, 3406B, 3406C, 3406E, 3408, 3408B, 3408C, 3412, 3412C, 3412E
3T5425	ARMATURE ASSEM.	594H, 657B, D8K
4M1868	ARMATURE AS	12E, 140G, 14E, 1673, 1673C, 1676, 16G, 215, 225, 235, 245, 3208, 3304, 3306, 3306B, 3406, 3406B, 3408, 3412, 3508, 3512, 3516, 572G, 627E, 637E, 776, 777, 815B, 826C, 920, 930, 950, 950B, 955H, 955K
4M8463	ARMATURE ASSEM.	12E, 561B, 651, 834, 955H, 977H, 988, D320A, D342, D342C, D343, D8H, D9E, D9G
5L8877	ARMATURE AS	1673C, 215, 3304, 3306, 3306B, 920, 943, 950, 950B, 951B, 963, D250B, D25C, D300B, D30C, D320A, D350C, D35C, D4D, D4E, D5B, D6C, G936, IT28, IT28B
7L6587	ARMATURE AS	1140, 1150, 1160, 1673B, 1673C, 1676, 3204, 3208, 3304, 3306, 3406, 3406B, D320A, G3304
7M8651	ARMATURE AS	1090, 1190, 1190T, 120M, 120M 2, 1290T, 12M 2, 12M 3, 12M 3 AWD, 1390, 140M, 140M 2, 140M 3, 140M 3 AWD, 14H, 14M, 160M, 160M 2, 160M 3, 160M 3 AWD, 16H NA, 16M, 2290, 235, 235D, 2390, 2391, 245, 2491
7T3275	ARMATURE AS	1673C, 3116, 3126, 3126B, 3176, 3176B, 3176C, 3196, 3204, 3208, 3304, 3306, 3306B, 3306C, 3406B, 3406C, 3406E, 480, 573, 65C, 65E, 75, 75C, 75D, 75E, 85C, 85D, 85E, 95E, C-10, C-12, C-15, C-16, C-18
7T3276	ARMATURE AS	120G, 120M, 12G, 12H, 12H ES, 12H NA, 12M, 130G, 140G, 140H, 140H ES, 140H NA, 140M, 143H, 14G, 14H, 14H NA, 14M, 160G, 160H, 160H ES, 160H NA, 160M, 163H, 163H NA, 1673C, 16G, 16H, 16H NA, 16M, 215B
7T6091	ARMATURE AS	CS-323
7X1951	ARMATURE AS	214B, 224B, 3116, 3126, 3126B, 3126E, 320 L, 320B, 322, 322B L, 322B LN, 322C, 322C FM, 324D, 324D LN, 325, 325B, 325B L, 325C, 325C FM, 325D, 325D L, 533, 539, 543, 613C II, 950F, 953C, 963B, 963C
8S1546	ARM AS	130G, 140G, 16G, 215, 235, 245, 3208, 3304, 3306, 3306B, 3406, 3406B, 3408, 3412, 3508, 3512, 3516, 572G, 627E, 637E, 815B, 826C, 920, 950B, 963, 966C, 977K, 980C, D4D, D5H, D6D, D7G, PR-750B
9S6100	ARMATURE AS	120G, 3208, 3304, 3306, 3306B, 518, 561C, 613, 613B, 613C, 920, 930, 950B, 951B, 955L, 963, D4D, D4E, D5H, D6C, G936
9X0338	ARMATURE & DRIVE AS	910
9X1280	ARMATURE AS	205B, 3114, 918F, 924F, 924G, 924H, 924HZ, 928H, 928HZ, AP-600D, AP-655D, AP555E, BG500E, BG600D, BG655D, C6.6, CB-434, CP-56, CP-573E, CP-64, CP-663E, CP-76, CS-56, CS-563E, CS-56B, CS-583E, CS-64

* Other part no. not included in the list are available. Please contact your sales representative if you have any questions. Part Numbers are used for reference purposes only.