



AIR FILTER INDICATOR

Knowing when to change the air filter of your machine is very critical. Replacing air filters too soon, increases maintenance cost. While replacing an air filter too late, reduces airflow and engine performance. Visual Inspection of an air filter is not a satisfactory way of determining when a filter needs replacing. An air filter change indicator is the most reliable way to determine when an air filter needs replacing.

Air Filters Indicators:

1. Maximize filter life.
2. Reduce maintenance cost by avoiding unnecessary filter changes.
3. Helps in managing maintenance intervals by Indicating the remaining life of the filter.
4. Improve engine performance by indicating when a filter change is required.

Part No.	Description	Application
0965028	INDICATOR-AIR FILTER	300.9D, 301.4C, 301.6C, 301.7D, 3014, 302.2D, 302.4D, 302.5C, 302.7D, 3024, 3024C, 303.5C, 303.5D, 303.5E, 303C CR, 303E CR, 304, 304C CR, 304D CR, 304E, 305, 305.5, 305.5D, 305.5E, 3054, 305C CR
1W0613	INDICATOR AS-AIR FILTER CHANGE	120B, 120G, 12G, 130G, 140B, 140G, 14G, 160G, 1673C, 16G, 215D, 225D, 227, 229, 229D, 231D, 235C, 235D, 245B, 245D, 3114, 3116, 3126, 3126B, 3126E, 3208, 3304, 3304B, 3306, 3306B, 3306C, 3408, 3408B
6I2933	INDICATOR-AIR FILTER SERVICE	1090, 1190, 1190T, 1290T, 1390, 30/30, 3114, 3116, 3412C, 3412E, 3508, 3508B, 3508C, 3512, 3512B, 3512C, 3516, 3516B, 3516C, 554, AP-800C, AP555E, BG-225B, BG-225C, BG500E, C13, C15, C15 I6, C18, C18
7S0687	INDICATOR-AIR FILTER CHANGE	120B, 12E, 12F, 16, 3116, 3126, 3126B, 3208, 3304, 3304B, 3306, 3306B, 3306C, 3406, 3406B, 3406C, 3406E, 3408, 3408C, 3412, 3412C, 3412E, 3456, 518, 528, 561D, 571G, 572G, 574, 583K, 594H, 621B
7W7417	INDICATOR AS	416B, 416C, 416D, 420D, 424B, 424B HD, 424D, 426C, 428B, 428C, 428D, 430D, 432D, 436C, 438C, 438D, 442D, 5130, 5130B, 5230, 5230B, 776C, 776D, 777B, 777D, 784B, 784C, 785B, 785C, 789B, 789C, 793B
8N2694	INDICATOR-AIR FILTER CHANGE	120H, 120H ES, 120H NA, 12G, 12H, 12H ES, 12H NA, 135H, 135H NA, 140H, 140H ES, 140H NA, 143H, 14H, 14H NA, 160H, 160H ES, 160H NA, 160K, 163H, 163H NA, 16H, 16H NA, 2290, 2390, 2391, 2491, 24H

* Other part no. not included in the list are available. Please contact your sales representative if you have any questions. Part Numbers are used for reference purposes only.